

Certificate of Conformance



3.2E

calibration date

03/11/2006

Calibration Data: Room Temperature

	X Axis	Y Axis	Z Axis
Zero-G Voltage	2.513	2.490	2.502
Sensitivity	0.497	0.505	0.505

Part Number	CXL04LP3
Serial Number	0621002373

Options:	DC Coupled
-----------------	------------

Wiring Diagram:

Color	Pin	Function
Red	1	5 Vdc
Black	2	Ground
White	3	X-axis
Yellow	4	Y-axis
Green	5	Z-axis

Thank you for choosing a Crossbow sensor. This worksheet is designed to help you get started. Refer to the product data sheet for more complete information.

Definitions

Zero-G Voltage : This number is the output voltage of the sensor with zero applied acceleration measured at the factory on the day of the calibration.

Sensitivity : This number is the sensor's sensitivity in Volts per G.

Calibration

The simplest method of field calibration is to record the sensor's output voltage when exposed to the Earth's gravitational field. Expose the sensor to +1G to obtain a more positive reading than the zero-G voltage. Expose the sensor to -1G to obtain a more negative reading than the zero-G voltage. The offset is defined as the average of the +1G and -1G voltages. The sensitivity in Volts per G is one-half the difference of the +1G and -1G voltages. Please note that this technique only works on DC coupled sensors. If your sensor is AC coupled, a shaker is required for proper calibration.

Technical Support

For further technical assistance, contact Crossbow Technology.

Crossbow Technology, Inc.
41 East Daggett Drive
San Jose, CA 95134

Phone : 408.965.3300
Fax : 408.324.4840
URL : <http://www.xbow.com>
Email : info@xbow.com