

## Calibration Data: Room Temperature

	X Axis	Y Axis	Z Axis
Zero-G Voltage	2.512	2.469	2.530
Sensitivity	0.492	0.492	0.493

Part Number	CXL04LP3
Serial Number	2002163

Options:	DC Coupled
----------	------------

### Wiring Diagram:

Color	Pin	Function
Red	1	5 Vdc
Black	2	Ground
White	3	X-axis
Yellow	4	Y-axis
Green	5	Z-axis

Thank you for choosing a Crossbow sensor. This worksheet is designed to help you get started. Refer to the product data sheet for more complete information.

#### Definitions

**Zero-G Voltage** : This number is the output voltage of the sensor with zero applied acceleration measured at the factory on the day of the calibration.

**Sensitivity** : This number is the sensor's sensitivity in Volts per G.

#### Calibration

The simplest method of field calibration is to record the sensor's output voltage when exposed to the Earth's gravitational field. Expose the sensor to +1G to obtain a more positive reading than the zero-G voltage. Expose the sensor to -1G to obtain a more negative reading than the zero-G voltage. The offset is defined as the average of the +1G and -1G voltages. The sensitivity in Volts per G is one-half the difference of the +1G and -1G voltages. Please note that this technique only works on DC coupled sensors. If your sensor is AC coupled, a shaker is required for proper calibration.

#### Technical Support

For further technical assistance, contact Crossbow Technology.

Crossbow Technology, Inc.  
41 East Daggett Drive  
San Jose, CA 95134

Phone : 408.965.3300  
Fax : 408.324.4840  
URL : <http://www.xbow.com>  
Email : [info@xbow.com](mailto:info@xbow.com)